

Download Suunto Vyper Air Manual

5.6.3. Transmitting data After the pairing procedure, the Suunto Vyper Air will receive cylinder pressure data from the transmitter. The pressure is displayed in either bars or psi, depending on the unit selected. Any time the Suunto Vyper Air receives an appropriate signal, the wireless transmitter indicator is displayed in the lower left corner. The VYPER is designed to comply with this standard draft. Page 4 ISO 9001 SUUNTO Oyj's Quality Assurance System is certified by Det Norske Veritas to be according to the ISO 9001 in all SUUNTO Oyj's operations (Quality Certificate No. 96-HEL-AQ-220). SUUNTO Oyj does not assume any responsibility for losses or claims by third parties ... Take the Suunto Vyper . AIR. wrist unit close to the transmitter. The unit will then quickly display the selected code number and then start displaying the transmitted cylinder pressure. The wireless transmitter indicator is displayed every time the Suunto Vyper. AIR. receives a valid signal. WARNING. If there are several divers using Suunto ...